How to Apply Your Melges 15 Bow Numbers

Application

Note: There is a port and starboard number. The slant should always go aft.

1. Make sure the application surface is clean.
2. Mark out with pencil 2.5 inches down from inside of gunwale and 2.5 inches back from Melges Logo. It is helpful to mark down from the gunwale in both the front and back of where you will be applying the bow number to ensure the number is level with the gunwale.
3. Spray hull down with a mist of water - a spray bottle is typically the best option.
4. Remove the sticker backing and spray the wack of the sticker with water.
5. Apply to the hull, ensuring the bow number lines up with the pencil marks. Once satisfied with the location, use a squeegee to remove all air.
6. Let sit for at least 30 minutes before removing the protective layer.