HOW TO USE YOUR MELGES 19 RUDDER SYSTEM

- Never sail without the rudder pin in place
- Never sail with the lever off
- Lever on or off – do not tighten
- Lever off – rudder fall down, push forward, insert pin, lever on
- Reverse steps to raise rudder, pin in center bottom hole, to hold rudder up
- Lever of when boat is resting to relax head
- Plastic pin is meant to break on grounding
- Only use stainless pin when you are 100% sure on water depth

MELGES19.COM